BASIC OPERATION GUIDE

This guide provides basic operational instructions pertaining to the components, devices, or equipment that may be installed on your motorhome. Please refer to the component manufacturer owner's manual for safety, troubleshooting, maintenance, and more detailed operating information.



Made to fit.

Monitor Panel

BASIC OPERATION

Conveniently located just inside the main entry of the motorhome, the monitor panel contains several useful features and system controls. Although monitor panels may vary by motorhome model and available features, in their basic form, the monitor panel provides these functions:

- Generator START (ON)/STOP (OFF) switch and hour meter
- Slideout EXTEND and RETRACT switch
- House (auxiliary) battery condition
- Fluid level Monitoring of the holding tanks (full to empty)
- Propane level within the LP tank
- Water heater ON/OFF switch
- Water pump ON/OFF switch
- Holding tank heaters ON/OFF switch (optional on some models)

To monitor the fluid level within the holding tanks, propane level within the LP tank, or monitor the energy level of the auxiliary batteries:

- 1. Press and hold the Selection Buttons that correspones to the tank (holding or LP) or battery
- One of the 4 LED indicator lights will illuminate, indicating an approximate level of a tank or an approximate charge condition of the auxiliary battery

AWARNING

Extinguish all pilot lights and igniters anytime the motorhome is in motion or refueling. This is accomplished by turning OFF the water heater, all propane appliances, and the propane gas supply (at the propane tank valve).

COMPONENT MANUFACTURER: KIB Electronics

TMC PART NUMBERS: 0320882

0326090 0326154 0356654 0365927 0326092 0327596 0362727 0377284 0326152 0356653 0365044 0398474

Typical Monitor Panel





LED Condition or Level Indicators

Battery Condition

L = Low

F = Fair

G = Good

C = Full Charge

Selection Buttons

